




DYNA-KING, INC.®
World's finest handcrafted flytying vises

THE BARRACUDA & BARRACUDA JR.




PARTS LIST Figure 1

- | | |
|------------------------------------------------------|------------------------------------------------|
| 1. Bearing Housing | 15. Cam Pin |
| 2. Body | 16. Set Collar -available on clamp models only |
| 3. Cam Handle | 17. Extra Large Pedestal Base |
| 4. Centering Gauge-available separately for purchase | 18. Base Lock Screw |
| 5. Tension Screw | 19. Base Feet |
| 6. Forcing Cone | 20. Name Plate |
| 7. Slide Lock Screw | 21. Bobbin Hanger Wire |
| 8. Jaw | 22. Bobbin Hanger Mount |
| 9. Rotary Lock Screw | 23. Bobbin Rest |
| 10. Hub Handle | 24. Bobbin Hanger Screw |
| 11. Hub | 25. Built In Material Clip |
| 12. Shaft Adaptor | 26. Serial Number |
| 13. Shaft | 27. Hub Handle Ball |
| 14. Spindle | 28. Set Screw (3) |

The Barracuda Junior comes with all components listed with the exception of the following:
1. Double Material Clip in place of the Single Material Clip Shown in diagram (#25)

Figure 2



PARTS LIST Figure 2

- | | |
|----------------------|------------------------------------------------|
| 1. Clamp Base | 7. Top View of Clamp with Outtrigger installed |
| 2. Clamp Shoe | 8. Side View Of Outtrigger |
| 3. Clamp Handle Knob | |
| 4. Clamp Screw | |
| 5. Clamp Lock Screw | |
| 6. Outtrigger | |

Clamp Vises come with a 9" shaft. Pedestals come with a 7" shaft.

597 SANTANA DRIVE, UNIT A • CLOVERDALE, CA 95425, USA
(707) 894-5566 • FAX (707) 894-5990 • www.dyna-king.com • info@dyna-king.com