




# DYNA-KING, INC.®

World's finest handcrafted flytying vises

## The TREKKER


Figure 1



**PARTS LIST**  
Figure 1

- |                    |                         |
|--------------------|-------------------------|
| 1. Jaw             | 13. Slide Lock Screw    |
| 2. Forcing Cone    | 14. Bobbin Hanger Mount |
| 3. Vise body       | 15. Bobbin Hanger Wire  |
| 4. Cam Handle      | 16. Bobbin Rest         |
| 5. Sleeve Adaptor  | 17. Bobbin Hanger Screw |
| 6. Spindle         | 18. Large Pedestal Base |
| 7. Bearing Housing | 19. Base Lock Screw     |
| 8. Tension Screw   | 20. Name Plate          |
| 9. Hub             | 21. Base Feet           |
| 10. Hub Handle     | 22. Set Screw           |
| 11. Shaft          | 23. Serial Number       |
| 12. Cam Pin        |                         |

Figure 2



**PARTS LIST**  
Figure 2

- |                      |                           |
|----------------------|---------------------------|
| 1. Clamp Base        | with Outrigger installed  |
| 2. Clamp Shoe        |                           |
| 3. Clamp Handle Knob | 8. Side View of Outrigger |
| 4. Clamp Screw       |                           |
| 5. Clamp Lock Screw  |                           |
| 6. Outrigger         |                           |
| 7. Top View of Clamp |                           |

The **SHAFT** of the **TREKKER** is threaded at the top & screws into the **BEARING HOUSING (#7)**. To remove the **SHAFT (#11)** it must be clamped into a bench vise. Use a cloth to wrap around the **SHAFT** so it won't be marred. Just grasp the Top portion of the vise and unscrew. When replacing the **SHAFT** be sure to not cross thread the **SHAFT** or **BEARING HOUSING** & tighten until very snug to prevent your vise from coming loose from the **SHAFT** while tying.

The pedestal version does not come with a Set Collar. The clamp version comes with a Delrin Set Collar.